



Safety Instructions

Read and understand the users manual carefully before using watchX.

Caution: Do not try to modify or fix watchX. The watchX is not user serviceable.

Caution: Use the watchX with caution and in accordance with local traffic regulations.

To avoid the risk of injury or damage, always follow these basic precautions.

Only use the watchX in accordance with the specifications outlined in this manual and on www.watchx.io

Do not attempt to repair or adjust any electrical or mechanical functions of this device. Tempering with these conditions may create a hazardous condition and will void your warranty.

Use restrictions

Do not temper or abuse your watchX including, without limitation, do not drop, disassemble, puncture, crush, throw, glue, paint or deform your watchX.

Prevent the watchX from getting in contact with any kind of liquid or moisture.

Do not clean your watchX with any kind of wet towel or hot air source.

Do not blow pressurized air on to the watchX.

Do not try to remove any electronic component from watchX board and do not solder on watchX PCB. This will void your warranty.

Do not place watchX near open flames or excessive heat, such as candles, fireplaces or cooktops.

Do not bring sharp objects in contact with the watchX to avoid scratches and damage.

Avoid temperatures below -10C/14F and above 50C/122F.

Battery and charging

Only use the battery supplied with watchX.

Only replace the watchX battery with an original watchX battery.

Do not tamper with the battery.

Do not drop, crush throw paint, glue, puncture or deform the battery.

Do not make any modifications to the battery.

Do not make any solder on the battery. This may create hazardous conditions.

Do not tamper with, or make any modifications to the battery cables and the battery connectors located on the watchX PCB and connected on the battery cable.

Only use the charging cable supplied with the watchX.

Do not use 3rd party charging cables.

Only charge with USB Compliant ports and chargers.

Only program your watchX with USB Compliant ports.

Do not charge the watchX if it's wet.

Do not clean your watchX when it's being charged.

Do not dispose the watchX battery into fire. It may explode and can cause injury.

Medical Device Interference

watchX contains components and radios that emit electromagnetic fields. Maintain a safe distance of separation between your medical device and the watchX. If you suspect any kind of interference with your pacemaker or any other medical device, stop using the watchX. Consult this condition with your physician/doctor and medical device manufacturer.



© 2018 argeX. All rights reserved.

watchX® and argeX® names and logos are trademarks of argeX.

www.argex.io

It is forbidden to
modify, print, publish or distribute this document in the digital or physical environment
without the permission of argeX.